



PAX A80 & A920 Connections

For your device to communicate with processing systems or download applications it needs a communication method such as Wi-Fi. Use the table below as a guide to connect your device to Wi-Fi.

The PAX A80 device supports additional communication methods like Ethernet or dial-up using a standard phoneline. Simply connect the cable to the applicable port on the bottom of the device (use LAN port for an Ethernet cable or LINE port for a phone cable). Your device will automatically connect when the device is connected to power.

Step-by-step Wi-Fi Connection Guide

Action	Screen View
<p>To connect to Wi-Fi, use two fingers and drag them down from the top of the screen to access the Android Quick Settings panel.</p> <p>When the panel appears, you will notice a small arrow to the right of the Wi-Fi label.</p> <p>Tap the small arrow.</p>	
<p>Turn on Wi-Fi by sliding the toggle to see a list of the available Wi-Fi networks in range.</p> <p>Select your Wi-Fi network from the list and enter the password using the virtual on-screen keyboard, then select CONNECT.</p> <p>Device will obtain an IP address, connect to the network and indicate connection.</p>	
<p>Upon successful connection, device will obtain an IP address, connect to the network, and indicate connection.</p> <p>Select the square icon at the bottom of the screen to close Wi-Fi settings:</p> <ul style="list-style-type: none"> On the PAX A920 select Clear All button On the PAX A80 select the 'X' in the top right corner of the application window. 	