




## PAX A80 Static IP with Ethernet Connection

For your device to communicate with processing systems or download payment applications it needs an Internet connection. Use the table below as a guide to connect your device to a Static IP utilizing an Ethernet cable.

To begin, simply connect the Ethernet cable to the LAN port on the bottom of the device.

### Step-by-step Ethernet & Static IP Connection Guide

Action	Screen View
<p>Navigate to the <b>Settings</b> app. The settings application is represented by a cog icon and may be placed on a different screen. To access different screens swipe left or right on the two horizontal dots near the bottom of the screen.</p> <p>Enter <b>9 8 7 6</b> as device password.</p> <p>Select <b>OK</b></p>	 <p>The first screenshot shows the home screen with the Settings app icon circled in green. The second screenshot shows the password entry screen with the password field and OK/CANCEL buttons circled in green.</p>
<p>Select <b>Ethernet</b> from the Wireless &amp; Networks section.</p> <p><b>Turn on Ethernet</b> by sliding the toggle to the right.</p> <p>Tap <b>Ethernet IP Mode</b>.</p>	 <p>The first screenshot shows the Settings app with the Ethernet option circled in green. The second screenshot shows the Ethernet settings page with the Ethernet toggle and Ethernet IP mode option circled in green.</p>
<p>Select <b>Static</b> as the Ethernet IP mode.</p> <p>Scroll down in the dialogue box and the requested information using the virtual keyboard or physical keypad.</p> <ul style="list-style-type: none"><li>• IP Address</li><li>• Gateway</li><li>• Netmask</li><li>• DNS 1</li><li>• DNS 2</li></ul> <p>Select <b>Connect</b> after entry of all information</p>	 <p>The first screenshot shows the Ethernet IP mode dialog box with the static option circled in green. The second screenshot shows the Ethernet settings page with the IP address and gateway fields filled in and the Connect button circled in green.</p>